

1.2 INSTALLATION

Fig. 1.2 (a) and (b) show the robot base dimensions. Avoid placing any object in front of the robot on the locating surface to facilitate the installation of the mastering fixture. (Shaded portion)

NOTE

For the R-2000iC/165R/210R, the mastering fixture is placed below the J1 base installation surface.




Fig. 1.2 (a) Dimensions of the robot base (R-2000iC/165F/210F/240F/125L/220U/165R/210R)